



































MLCC APPLICATION GUIDE


No.	Process	Condition																		
1	Operating Condition (Storage)	1) The capacitor must be stored in an ambient temperature between 5 ~ 40°C with a relative humidity of 20 ~ 70%. The products should be used within 12 months upon receipt. 2) The capacitors must be operated and stored in an environment free of dew condensation and these gases such as Hydrogen Sulphide, Hydrogen Sulfate, Chlorine and Ammonia and sulfur. 3) Avoid storing in direct sunlight and falling of dew. 4) Do not use capacitors under high humidity and high and low atmospheric pressure which may affect capacitors reliability.																		
2	Circuit design ! Caution	2-1 Operating temperature Operating temperature should be followed strictly within this specification, especially be careful with maximum temperature. 1) Do not use capacitor above the maximum allowable operating temperature. 2) Surface temperature including self heating should be below maximum operating temperature. (Due to dielectric loss, capacitor will heat itself when AC is applied. Especially at high frequencies around its SRF, the heat might be so extreme that it may damage itself or the surrounding area. Please design the circuit so that the maximum temperature of the capacitor including the self heating to be below the maximum allowable operating temperature. Temperature rise shall be below 20°C) 2-2 Operating voltage 1) Operating voltage across the terminals should be below the rated voltage. When AC and DC are super imposed, the peak must be below the rated voltage. With AC or pulse overshooting, Vp-p must be below the rated voltage. -----(1)&(2) AC or Pulse with overshooting, Vp-p must be below the rated voltage. -----(3),(4)&(5) When the voltage is started to apply to the circuit or it is stopped applying, the irregular voltage may be generated for a transit period because of resonance or switching. Be sure to use a capacitor within rated voltage containing these irregular voltage.																		
<table border="1"> <thead> <tr> <th data-bbox="344 1413 528 1447">Voltage</th> <th data-bbox="528 1413 711 1447">DC Voltage</th> <th data-bbox="711 1413 895 1447">DC+AC Voltage</th> <th data-bbox="895 1413 1078 1447">AC Voltage</th> <th data-bbox="1078 1413 1262 1447">Pulse Voltage (1)</th> <th data-bbox="1262 1413 1430 1447">Pulse Voltage (2)</th> </tr> </thead> <tbody> <tr> <td data-bbox="344 1447 528 1619">Positional Measurement</td> <td data-bbox="528 1447 711 1619">  </td> <td data-bbox="711 1447 895 1619">  </td> <td data-bbox="895 1447 1078 1619">  </td> <td data-bbox="1078 1447 1262 1619">  </td> <td data-bbox="1262 1447 1430 1619">  </td> </tr> <tr> <td></td> <td data-bbox="528 1581 552 1615">(1)</td> <td data-bbox="711 1581 735 1615">(2)</td> <td data-bbox="895 1581 919 1615">(3)</td> <td data-bbox="1078 1581 1102 1615">(4)</td> <td data-bbox="1262 1581 1286 1615">(5)</td> </tr> </tbody> </table>			Voltage	DC Voltage	DC+AC Voltage	AC Voltage	Pulse Voltage (1)	Pulse Voltage (2)	Positional Measurement							(1)	(2)	(3)	(4)	(5)
Voltage	DC Voltage	DC+AC Voltage	AC Voltage	Pulse Voltage (1)	Pulse Voltage (2)															
Positional Measurement																				
	(1)	(2)	(3)	(4)	(5)															
2) Even below the rated voltage, if repetitive high frequency AC or pulse is applied, the reliability of the capacitor may be reduced. 3) Voltage derating will greatly reduce the failure rate. Since the failure rate follows the 3 power law of voltage, the failure rate used under Uw with UR rated product will be lowered as $(Uw/UR)^3$.																				

No.	Process	Condition																																																																																																																																																
3	Designing P.C. board	<p>The amount of solder at the terminations has a direct effect on the reliability of the capacitor.</p> <ol style="list-style-type: none"> 1) The greater the amount of solder, the higher the stress on the chip capacitor, and the more likely that it will break. When designing a P.C. board, determine the shape and size of the solder pads to have proper amount of solder on the terminations. 2) Avoid using common solder pads for multiple terminations and provide individual solder pads for each terminations. <p>See the following table for recommended pad dimensions.</p> <div data-bbox="501 607 1374 1025" data-label="Diagram"> <p>The diagram illustrates the footprint dimensions for a capacitor. It shows a central capacitor body with two solder pads on either side. Dimensions are labeled as follows: A is the total width of the pads; B is the width of the central gap; C is the width of the left pad; D is the width of the right pad; E is the width of the central gap; F is the total width including the central gap; G is the height of the pads; and H is the height of the central gap. A legend identifies the patterns: a red dashed box for 'Occupied area', a black solid box for 'Solder land / Solder paste pattern', a blue dashed box for 'Solder resist pattern', and an orange solid box for 'Tracks or Dummy tracks (for wave soldering only)'.</p> </div>																																																																																																																																																
Reflow Soldering																																																																																																																																																		
		<table border="1"> <thead> <tr> <th rowspan="2">SIZE</th> <th colspan="7">Footprint dimensions in mm</th> <th rowspan="2">Processing remarks</th> <th rowspan="2">Placement Accuracy</th> </tr> <tr> <th>A</th> <th>B</th> <th>C</th> <th>D</th> <th>E</th> <th>F</th> <th>G</th> </tr> </thead> <tbody> <tr> <td>01005</td> <td>0.45</td> <td>0.20</td> <td>0.15</td> <td>0.21</td> <td>N/A</td> <td>0.65</td> <td>0.38</td> <td rowspan="14">Reflow or hot plate soldering</td> <td>± 0.05</td> </tr> <tr> <td>0201</td> <td>0.65</td> <td>0.23</td> <td>0.21</td> <td>0.30</td> <td>N/A</td> <td>0.90</td> <td>0.60</td> <td>± 0.05</td> </tr> <tr> <td>0402</td> <td>1.50</td> <td>0.50</td> <td>0.50</td> <td>0.50</td> <td>0.10</td> <td>1.75</td> <td>0.95</td> <td>± 0.15</td> </tr> <tr> <td>0508</td> <td>2.50</td> <td>0.50</td> <td>1.00</td> <td>2.00</td> <td>0.15</td> <td>2.90</td> <td>2.40</td> <td>± 0.20</td> </tr> <tr> <td>0603</td> <td>2.30</td> <td>0.70</td> <td>0.80</td> <td>0.80</td> <td>0.20</td> <td>2.55</td> <td>1.40</td> <td>± 0.25</td> </tr> <tr> <td>0612</td> <td>2.80</td> <td>0.80</td> <td>1.00</td> <td>3.20</td> <td>0.20</td> <td>3.08</td> <td>3.85</td> <td>± 0.25</td> </tr> <tr> <td>0805</td> <td>2.80</td> <td>1.00</td> <td>0.90</td> <td>1.30</td> <td>0.40</td> <td>3.05</td> <td>1.85</td> <td>± 0.25</td> </tr> <tr> <td>1206</td> <td>4.00</td> <td>2.20</td> <td>0.90</td> <td>1.60</td> <td>1.60</td> <td>4.25</td> <td>2.25</td> <td>± 0.25</td> </tr> <tr> <td>1210</td> <td>4.00</td> <td>2.20</td> <td>0.90</td> <td>2.50</td> <td>1.60</td> <td>4.25</td> <td>3.15</td> <td>± 0.25</td> </tr> <tr> <td>1808</td> <td>5.40</td> <td>3.30</td> <td>1.05</td> <td>2.30</td> <td>2.70</td> <td>5.80</td> <td>2.90</td> <td>± 0.25</td> </tr> <tr> <td>1812</td> <td>5.30</td> <td>3.50</td> <td>0.90</td> <td>3.80</td> <td>3.00</td> <td>5.55</td> <td>4.05</td> <td>± 0.25</td> </tr> <tr> <td>2211</td> <td>7.00</td> <td>4.30</td> <td>2.00</td> <td>3.70</td> <td>N/A</td> <td>7.60</td> <td>4.10</td> <td>± 0.30</td> </tr> <tr> <td>2220</td> <td>7.00</td> <td>4.30</td> <td>2.00</td> <td>5.00</td> <td>N/A</td> <td>7.60</td> <td>5.50</td> <td>± 0.30</td> </tr> <tr> <td>2225</td> <td>7.00</td> <td>4.30</td> <td>2.00</td> <td>6.73</td> <td>N/A</td> <td>7.60</td> <td>7.00</td> <td>± 0.30</td> </tr> </tbody> </table>	SIZE	Footprint dimensions in mm							Processing remarks	Placement Accuracy	A	B	C	D	E	F	G	01005	0.45	0.20	0.15	0.21	N/A	0.65	0.38	Reflow or hot plate soldering	± 0.05	0201	0.65	0.23	0.21	0.30	N/A	0.90	0.60	± 0.05	0402	1.50	0.50	0.50	0.50	0.10	1.75	0.95	± 0.15	0508	2.50	0.50	1.00	2.00	0.15	2.90	2.40	± 0.20	0603	2.30	0.70	0.80	0.80	0.20	2.55	1.40	± 0.25	0612	2.80	0.80	1.00	3.20	0.20	3.08	3.85	± 0.25	0805	2.80	1.00	0.90	1.30	0.40	3.05	1.85	± 0.25	1206	4.00	2.20	0.90	1.60	1.60	4.25	2.25	± 0.25	1210	4.00	2.20	0.90	2.50	1.60	4.25	3.15	± 0.25	1808	5.40	3.30	1.05	2.30	2.70	5.80	2.90	± 0.25	1812	5.30	3.50	0.90	3.80	3.00	5.55	4.05	± 0.25	2211	7.00	4.30	2.00	3.70	N/A	7.60	4.10	± 0.30	2220	7.00	4.30	2.00	5.00	N/A	7.60	5.50	± 0.30	2225	7.00	4.30	2.00	6.73	N/A	7.60	7.00	± 0.30
SIZE	Footprint dimensions in mm							Processing remarks	Placement Accuracy																																																																																																																																									
	A	B	C	D	E	F	G																																																																																																																																											
01005	0.45	0.20	0.15	0.21	N/A	0.65	0.38	Reflow or hot plate soldering	± 0.05																																																																																																																																									
0201	0.65	0.23	0.21	0.30	N/A	0.90	0.60		± 0.05																																																																																																																																									
0402	1.50	0.50	0.50	0.50	0.10	1.75	0.95		± 0.15																																																																																																																																									
0508	2.50	0.50	1.00	2.00	0.15	2.90	2.40		± 0.20																																																																																																																																									
0603	2.30	0.70	0.80	0.80	0.20	2.55	1.40		± 0.25																																																																																																																																									
0612	2.80	0.80	1.00	3.20	0.20	3.08	3.85		± 0.25																																																																																																																																									
0805	2.80	1.00	0.90	1.30	0.40	3.05	1.85		± 0.25																																																																																																																																									
1206	4.00	2.20	0.90	1.60	1.60	4.25	2.25		± 0.25																																																																																																																																									
1210	4.00	2.20	0.90	2.50	1.60	4.25	3.15		± 0.25																																																																																																																																									
1808	5.40	3.30	1.05	2.30	2.70	5.80	2.90		± 0.25																																																																																																																																									
1812	5.30	3.50	0.90	3.80	3.00	5.55	4.05		± 0.25																																																																																																																																									
2211	7.00	4.30	2.00	3.70	N/A	7.60	4.10		± 0.30																																																																																																																																									
2220	7.00	4.30	2.00	5.00	N/A	7.60	5.50		± 0.30																																																																																																																																									
2225	7.00	4.30	2.00	6.73	N/A	7.60	7.00		± 0.30																																																																																																																																									

No.	Process	Condition																																																																											
3	Designing P.C. board (Continued)	<p>Wave Soldering</p> <table border="1"> <thead> <tr> <th rowspan="2">SIZE</th> <th colspan="7">Footprint dimensions in mm</th> <th rowspan="2">Proposed number & Dimensions of dummy tracks</th> <th rowspan="2">Placement Accuracy</th> </tr> <tr> <th>A</th> <th>B</th> <th>C</th> <th>D</th> <th>E</th> <th>F</th> <th>G</th> </tr> </thead> <tbody> <tr> <td>0603</td> <td>2.40</td> <td>1.00</td> <td>0.70</td> <td>0.80</td> <td>0.20</td> <td>3.10</td> <td>1.90</td> <td>1x (0.20x0.80)</td> <td>± 0.10</td> </tr> <tr> <td>0805</td> <td>3.20</td> <td>1.40</td> <td>0.90</td> <td>1.30</td> <td>0.36</td> <td>4.10</td> <td>2.50</td> <td>1x (0.30x1.30)</td> <td>± 0.15</td> </tr> <tr> <td>1206</td> <td>4.80</td> <td>2.30</td> <td>1.25</td> <td>1.70</td> <td>1.25</td> <td>5.90</td> <td>3.20</td> <td>3x (0.25x1.70)</td> <td>± 0.25</td> </tr> <tr> <td>1210</td> <td>5.30</td> <td>2.30</td> <td>1.50</td> <td>2.60</td> <td>1.25</td> <td>6.30</td> <td>4.20</td> <td>3x (0.25x2.60)</td> <td>± 0.25</td> </tr> </tbody> </table> <p>Footprint design for C Array :</p> <table border="1"> <thead> <tr> <th>Type</th> <th>0603*4</th> <th>0402*4</th> </tr> </thead> <tbody> <tr> <td>A</td> <td>2.85 +0.10/-0.05</td> <td>1.80 ± 0.10</td> </tr> <tr> <td>B</td> <td>0.45 ± 0.05</td> <td>0.25 ± 0.05</td> </tr> <tr> <td>D</td> <td>0.80 ± 0.10</td> <td>0.65 ± 0.05</td> </tr> <tr> <td>P</td> <td>0.80</td> <td>0.50</td> </tr> <tr> <td>F</td> <td>3.10 ± 0.30</td> <td>1.85 ± 0.25</td> </tr> </tbody> </table> 	SIZE	Footprint dimensions in mm							Proposed number & Dimensions of dummy tracks	Placement Accuracy	A	B	C	D	E	F	G	0603	2.40	1.00	0.70	0.80	0.20	3.10	1.90	1x (0.20x0.80)	± 0.10	0805	3.20	1.40	0.90	1.30	0.36	4.10	2.50	1x (0.30x1.30)	± 0.15	1206	4.80	2.30	1.25	1.70	1.25	5.90	3.20	3x (0.25x1.70)	± 0.25	1210	5.30	2.30	1.50	2.60	1.25	6.30	4.20	3x (0.25x2.60)	± 0.25	Type	0603*4	0402*4	A	2.85 +0.10/-0.05	1.80 ± 0.10	B	0.45 ± 0.05	0.25 ± 0.05	D	0.80 ± 0.10	0.65 ± 0.05	P	0.80	0.50	F	3.10 ± 0.30	1.85 ± 0.25
		SIZE		Footprint dimensions in mm									Proposed number & Dimensions of dummy tracks	Placement Accuracy																																																															
			A	B	C	D	E	F	G																																																																				
		0603	2.40	1.00	0.70	0.80	0.20	3.10	1.90	1x (0.20x0.80)	± 0.10																																																																		
		0805	3.20	1.40	0.90	1.30	0.36	4.10	2.50	1x (0.30x1.30)	± 0.15																																																																		
		1206	4.80	2.30	1.25	1.70	1.25	5.90	3.20	3x (0.25x1.70)	± 0.25																																																																		
		1210	5.30	2.30	1.50	2.60	1.25	6.30	4.20	3x (0.25x2.60)	± 0.25																																																																		
		Type	0603*4	0402*4																																																																									
		A	2.85 +0.10/-0.05	1.80 ± 0.10																																																																									
		B	0.45 ± 0.05	0.25 ± 0.05																																																																									
D	0.80 ± 0.10	0.65 ± 0.05																																																																											
P	0.80	0.50																																																																											
F	3.10 ± 0.30	1.85 ± 0.25																																																																											
3) Layout recommendation																																																																													
	<table border="1"> <thead> <tr> <th>Example</th> <th>Use of common solder land</th> <th>Soldering with chassis</th> <th>Use of common solder land with other SMD</th> </tr> </thead> <tbody> <tr> <td rowspan="2">Must be avoided</td> <td></td> <td></td> <td></td> </tr> <tr> <td rowspan="2">Recommended</td> <td></td> <td></td> <td></td> </tr> </tbody> </table>	Example	Use of common solder land	Soldering with chassis	Use of common solder land with other SMD	Must be avoided				Recommended																																																																			
Example	Use of common solder land	Soldering with chassis	Use of common solder land with other SMD																																																																										
Must be avoided																																																																													
	Recommended																																																																												

3 Designing P.C. board (Continued)

4) Mechanical stress varies according to location of chip capacitors on the P.C. board.



5) Recommended chip capacitor layout is as follows:





Subject	Disadvantage against bending stress	Advantage against bending stress
Mounting face	<p>Perforation & slit</p> <p>Direction of breaking</p> <p>Break P.C. board with mounted side up</p>	<p>Perforation & slit</p> <p>Direction of breaking</p> <p>Break P.C. board with mounted side down.</p>
Chip arrangement (Direction)	<p>Mount perpendicular to perforation or slit</p> <p>Direction of breaking</p>	<p>Mount in parallel with perforation or slit</p> <p>Direction of breaking</p>
Distance from slit	<p>Closer to slit is higher stress</p> <p>Direction of breaking</p> <p>Slit</p> <p>l_1</p> <p>$(l_1 < l_2)$</p>	<p>Away from slit is less stress</p> <p>Direction of breaking</p> <p>Slit</p> <p>l_2</p> <p>$(l_1 < l_2)$</p>

4 Mounting

4-1 Stress from mounting head


If the mounting head is adjusted too low, it may induce excessive stress in the chip Capacitor resulting in cracking. Please take the following precautions.

- 1) Adjust the bottom dead center of the mounting head to just on the P.C. board surface and not pressing on it.
- 2) Adjust the mounting head pressure to be 1 to 3N of static weight.
- 3) To minimize the impact energy from mounting head, it is important to provide support from the bottom side of the P.C. board.(see following)

Mounting	Not recommended	Recommended
Single sided		
Double sided		

When the centering jaw is worn out, it may give mechanical impact on the capacitor to cause a crack. Please control the close up dimension of the centering jaw and provide sufficient preventive maintenance and replacement of it.

4-2 Amount of adhesive



Example : 0805(2012) and 1206(3216)

Figure	0805/1206 case sizes as examples
a	0.2mm min
b	70 ~ 100 um
c	Do not touch the solder land

5 Soldering


5-1 Flux selection

Although highly-activated flux gives better solderability, substances which increase activity may also degrade the insulation of the chip capacitors. To avoid such degradation, the following is recommended.

- 1) It is recommended to use a mildly activated rosin flux (less than 0.1 wt% chlorine).
Strong flux is not recommended.
- 2) Excessive flux must be avoided. Please provide proper amount of flux.
- 3) When water-soluble flux is used, enough washing is necessary.

5-2 Recommended soldering profile by various methods

- 1) Recommended reflow soldering profile for SMT process with SnAgCu series solder paste



- 2) Wave soldering profile




Recommended wave soldering profile for SMT process with SnAgCu series solder.

Wave soldering is recommended only for the following case sizes:
0603(1608); 0805(2012)
& 1206(3216) thickness < 1mm

5 Soldering
(Continued)

3) Manual soldering (solder iron)



5-3 Avoiding thermal shock

1) Preheating condition


Soldering	Size	Temperature difference(ΔT)
Wave soldering	1206 (3216) or less	$\Delta T \leq 150^{\circ}\text{C}$
Reflow soldering	1206 (3216) or less	$\Delta T \leq 190^{\circ}\text{C}$
	1210 (3225) or more	$\Delta T \leq 130^{\circ}\text{C}$
Manual soldering	1206 (3216) or less	$\Delta T \leq 190^{\circ}\text{C}$
	1210 (3225) or more	$\Delta T \leq 130^{\circ}\text{C}$

2) Cooling condition

Natural cooling using air is recommended. If the chips are dipped into a solvent for cleaning, the temperature difference (ΔT) must be less than 100°C .

5-4 Amount of solder

Excessive solder will induce higher tensile force in chip capacitor when temperature changes and may result in chip cracking. Insufficient solder may detach the capacitor from the P.C. board.



5-5 Two times limitation for reflow soldering will be recommended.


5-6 Solder repair by solder iron

1) Selection of the soldering iron tip

Tip temperature of solder iron varies by its type, P.C. board material and solder pad size. Higher tip temperature may be faster, but the heat shock may crack the chip capacitor. (Following conditions are recommended.)

Size	Temp. (°C)	Preheating Temp. (°C)	Temperature difference(ΔT)	Atmosphere
1206 (3216) or less	330 ± 20°C	>150°C	ΔT ≤ 190°C	Room air
1210 (3225) or more	280°C Max	>150°C	ΔT ≤ 130°C	Room air

2) Direct contact of the soldering iron with ceramic dielectric of chip capacitor may cause cracking. Do not make contact directly with the ceramic dielectric.



6 Cleaning

1) If an unsuitable cleaning fluid is used, flux residue or some foreign article may stick to chip capacitor surface causing deteriorated performance, especially insulation resistance.

2) If the cleaning condition is not suitable, it may damage the chip

capacitor. 2-1) Insufficient washing

(1) Lead wire and terminal electrodes may corrode due to Halogen in the flux.

(2) Halogen in the flux may adhere on the surface of capacitor, and lower the insulation resistance.

(3) Water soluble flux has higher tendency to have the above mentioned problems (1) and

(2). 2-2) Excessive washing

When ultrasonic cleaning is used, excessively high ultrasonic energy output can affect the connection between the ceramic chip capacitor's body and the terminal electrode. To avoid this, use the following recommended condition.

Power : 20W/l max.

Frequency : 40kHz max.

Washing time : 5 minutes

max.

2-3) If the cleaning fluid is contaminated, the density of Halogen increases, and it may bring the same result as insufficient cleaning.

7 Coating and molding of the P.C. board

1) When the P.C. board is coated, verify the quality influence on the product.


2) Please verify that there is no harmful decomposing or reaction gas emission during curing which may damage the chip capacitor.

3) Please verify the curing temperature.

8 Handling after chip is mounted

1) Please pay attention not to bend or distort the P.C. board after soldering in handling and storage, otherwise the chip capacitor may crack .

Avoid the following:




2) When functional check of the P.C. board is performed, check pin pressure as it tends to be adjusted higher for fear of loose contact. If the pressure is excessive and bends the P.C. board, it may crack the chip capacitor or peel the terminations off. Adjust the check pins not to bend the P.C. board.

Item	Not recommended	Recommended
Board bending		

9 Handling of loose chip capacitor

1) If dropped the chip capacitor may crack. Once dropped do not use it. This is especially true for large case sized chips.



2) Avoid piling up P.C. boards after mounting. The corner of the P.C. board may hit the chip capacitor of another board causing the chip to crack or dislodge.

